


制作说明：A4对折

封面纸质：铜板纸

USER GUIDE

LiFepO4 Battery System for Households



5. Commissioning

Parallel in single phase



Step 1: Check the following requirements before commissioning:

- ⌘ Correct wire connection
- ⌘ Ensure all breakers in Line wires of load side are open and each Neutral wires of each unit are connected together.

Step 2: Turn on each unit and set “PAL” in LCD setting program 4 of each unit. And then shut down all units.

NOET: It’s necessary to turn off switch when setting LCD program. Otherwise, the setting can not be programmed.

Step 3: Turn on each unit.

LCD display in Master unit	LCD display in Slave unit
	

NOTE: Master and slave units are randomly defined.

Table Of Contents

1 About This Manual.....1

1.1 Purpose.....1

1.2 Scope.....1

2 Safety Instructions.....1

3 Introduction.....2

3.1 Features.....2

3.2 Basic System Architecture.....2

3.3 Product Overview.....3

4 Installation.....5

4.1 Unpacking And Inspection5

4.2 Preparation5

4.3 Mounting The Unit.....5

4.4 Battery Connection.....6

4.5 Ac Input/Output Connection.....7

4.6 PV Connection.....8

4.7 Final Assembly.....10

5 Operation.....10

5.1 Power On/off.....10

5.2 Operation and Display Panel.....11

5.3 LCD Setting.....18

5.4 Battery Equalization Description.....27

5.5 Fantion and alarm description.....29

6 Trouble removeal.....31

7 Technical datasheet.....32

Appendix I:Parallel function.....33

1 Mounting the Unit.....33

2 Wiring Connection.....33

3 PV Connection.....46

4 LCD Setting and Display.....46

5 Commissioning.....47

1 About This Manual

1.1 Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations, Keep manual for future reference.

1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

2 Safety Instructions

 **WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.**

1. Before using the unit read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION**-To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. Do not disassemble the unit Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION**-Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals, Please refer to INSTALLATION section of this manual for the details
10. One piece of 150A fuse is provided as over-current protection for the battery supply.
11. **GROUNDING INSTRUCTIONS** -This inverter/ charger should be connected to a permanent grounder wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. **NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **Warning!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.

3. PV Connection

Please refer to user manual of single unit for PV Connection
CAUTION: Each inverter should connect to PV modules separately.

4. LCD setting and display


Setting Program:

Program	Description	Selectable option	
04	AC output mode *This setting is only available when the inverter is in standby mode (Switch off).	Single: 	When the units are used in parallel with single phase, please select "PAL" in program 4.
		Parallel: 	It is required to have at least 3 inverters or maximum 9 inverters to support three-phase equipment. It's required to have at least one inverter in each phase or it's up to four inverters in one phase please-2 for detailed information. Please select "3P1" in program 4 for the inverters connected to phase, "3P2" in program 4 for the inverters connected to L2 phase and "3P3" in program 4 for the inverters connected to L3 phase. Be sure to connect share current cable to units which are on the same phase. Do NOT connect share current cable between units on different phases. Besides, power saving function will be automatically disabled.
		L1 phase: 	
		L2 phase: 	
		L3 phase: 	


Fault code display

Fault Code	Fault Event	Icon on
60	Power feedback protection	
71	Firmware version inconsistent	
72	Current sharing fault	
80	CAN fault	
81	Host loss	
82	Synchronization loss	
83	Battery voltage detected different	
84	AC input voltage and frequency detected different	
85	AC output current unbalance	
86	AC output mode setting is different	

Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




One inverter in each phase:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection



Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)



WARNING:Do not connect the current sharing cable between the inverters which are in different phases. Otherwise, it may damage the inverters.

3 Introduction

This is Energy Storage System, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current AC/solar charger priority, and acceptable input voltage based on different applications.

3.1 Features

- ♦ Pure sine wave inverter
- ♦ Configurable input voltage range for home appliances and personal computers via LCD setting
- ♦ Configurable battery charging current based on applications via LCD setting
- ♦ Configurable AC/Solar Charger priority via LCD setting
- ♦ Compatible to mains voltage or generator power
- ♦ Auto restart while AC is recovering
- ♦ Overload/Over temperature/short circuit protection
- ♦ Smart battery charger design for optimized battery performance
- ♦ Cold start function


3.2 Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- ♦ Generator or Utility
- ♦ PV modules


Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.




3.3 Product Overview

3.3.1 LCD Screen




- 1.....LCD display
- 2.....Status indicator
- 3.....Charging indicator
- 4.....Fault indicator
- 5.....ESC
- 6.....UP
- 7.....DOWN
- 8.....ENTER

3.3.2 Back Panel




- 1.....PV input switch
- 2.....AC input switch
- 3.....AC output switch
- 4.....AC input
- 5.....AC output
- 6.....Parallel connection




- 7.....Solar panel input
- 8.....Battery terminal positive
- 9.....Battery terminal negative
- 10....Dry contact
- 11....BMS/RS485 Communication port
- 12....RS232 Communication port

Two inverters in two phases and only one inverter for the remaining phase:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Two inverters in one phase and only one inverter for the remaining phases:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Three inverters in one phase and only one inverter for the remaining two phases:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)



Back panel wiring diagram



4 INSTALLATION


4.1 Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:

- ◆ The unit x 1
- ◆ User manual 1

4.2 Preparation


Before connecting all the wiring, please remove the side cover, as shown in the figure below.



4.3 Mounting the Unit


Consider the following points before selecting where to install:

- ※ Do not mount the inverter on flammable construction materials.
- ※ Mount on a solid surface
- ※ Inverter system is installed above the lithium battery.
- ※ In order to allow air to circulate and dissipate heat properly, please leave a gap of about 20CM on the side and 50CM above the device.
- ※ The ambient temperature should be between and to ensure optimal operation.
- ※ The recommended installation position is to be adhered to the wall vertically.
- ※ Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.




! SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Four inverters in one phase and one inverter for the other two phases:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Three inverters in one phase, two inverters in second phase and one inverter for the third phase:

Power Connection(Each photovoltaic panel needs to be connected to an independent system)




Three inverters in one phase, two inverters in second phase and two inverters for the third phase:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Two inverters in each phase:

Power Connection(Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Use M4 countersunk machine screws to install the fixed bracket to the chassis;


Use M6*80mm expansion screws to fix the chassis to the wall.



4.4 Battery Connection

CAUTION: For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to over-current protection installed. Please refer to typical amperage in below table as required fuse or breaker size.

Ring terminal:




WARNING! All wiring must be performed by be qualified personnel.
WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.

Recommended battery cable and terminal size:


Rated Capacity	Typical Amperage	Battery capacity	Wire Size	Ring Terminal			Torque value
				Cable(mm²)	Dimensions		
					D(mm)	L(mm)	
5.5KVA	121A	200AH	1*2AWG	34	6.4	39.2	2-3Nm
			2*6AWG	14	6.4	33.2	
11KVA	228A	250AH	1*3/0AWG	85	8.4	54	5Nm

please follow below steps to implement battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal size.



2. Insert the battery wires flatly into battery connectors of inverter and make sure the bolts are tightened with torque of 2 Nm in clockwise direction. Make sure polarity at both the battery and the inverter/charge is correctly connected and conductors are tightly screwed into the battery terminals.



WARNING: Shock Hazard
Installation must be performed with care due to high battery voltage in series.

CAUTION!! Before making the final DC connection or closing DC breaker/disconnector, be sure positive(+) must be connected to positive(+) and negative(-) must be connected to negative (-).

4.5 AC Input Output Connection

CAUTION!! Before connecting to AC input power source, please Install a separate AC breaker between inverter and AC input power source. This will ensure the Inverter can be disconnected during maintenance and fully protected from over current of AC input. The recommended spec of breaker is 32A for 24V system and 63A for 48V system .

CAUTION!! There are two terminal blocks with " IN " and " OUT " markings. Please do NOT mis-connect input and output connectors.

WARNING! All wiring must be performed by qualified personnel.
WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.


Suggested cable requirement for AC wires

Rated Capacity	Gauge	Torque value
5.5KVA	10AWG	1.4~1.6Nm
11KVA	8AWG	1.4~1.6Nm

2-2 Support 3-phase equipment

Three inverters in each phase:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)




Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Three inverters in one phase, three inverters in second phase and two inverters for the third phase:
Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)



Seven to nine inverters in parallel:

Power Connection(Each photovoltaic panel needs to be connected to an independent system)




Communication Connection


Seven inverters in parallel




Eight inverters in parallel



Nine inverters in parallel



Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Please follow below steps to implement AC input/ output connection

1. Before making AC input/output connection be sure to open DC protector or disconnecter first.
2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and neutral conductor N3 mm.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor(⊕)first.

⊕→Ground(yellow-green)

L→LINE(brown or black)

N→Neutral (blue)



WARNING:

Be sure that AC power source is disconnected before attempting to hardwire it to the unit.

4. Make sure the wires are securely connected

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/ charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

4.6 PV Connection

PV Connection(Only apply for the model with solar charger)

CAUTION:Before connecting to PV modules, please install **separately** a DC circuit breaker between inverter and PV modules.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Typical Amperage	Gauge	Torque Value
30A	12AWG	1.4~1.6Nm

PV module selection:

When choosing the right PV module, be sure to first consider the following requirements:



The open circuit voltage (Voc) of the PV modules does not exceed the maximum PV array open circuit voltage of the inverter. The maximum supply voltage of the PV modules should be close to the optimal PV access voltage range of the inverter for best performance. If one PV module cannot meet this requirement, it is necessary to connect multiple PV modules in series.

Model	5548MH	11048MH
PV Charging Mode	MPPT	双路MPPT
MAX.PV Input Power	8500W	2*5500W
MPPT Tracking Range	60~500Vdc	90~500Vdc
Best voltage	360~430V	300~400V
MAX.PV Input Voltage	500Vdc	500Vdc
MAX.PV Charging Current	100A	150A
MAX.AC Charging Current	100A	150A
MAX.Charging Current	100A	150A

PV Module Wire Connection


Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 10 mm for positive and negative conductors.
2. Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool
3. Fix wire cover to the inverter with supplied screws as shown in below chart.




4. Check correct polarity of wire from PV modules and PV input connectors. Then, connect positive pole(+) of connection wire to positive pole(+) of PV input connector. Connect negative pole(-) of connection wire to negative pole(-) of PV input connector. Screw two wires tightly in clockwise direction. Recommended tool: 4mm blade screwdriver.

Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Six inverters in parallel:

Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Four inverters in parallel:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




Five inverters in parallel:

Power Connection(Each photovoltaic panel needs to be connected to an independent system)




4.7 Final Assembly

After connecting all the wires, please tighten the two screws and put the side cover back in place, as shown below



5 OPERATION

5.1 Power ON/OFF



Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the button of the case) to turn on the unit.

5.1.1 Steps to start up

Connect the battery that meets the requirements (battery voltage needs to be beyond 23V) or AC (AC needs to confirm the suitable input range depend on the output mode), then you can start up the inverter.

➤ Mains power on

Connect to normal AC power, press the switch, the system will automatically turn on. If you set AC output power priority, after waiting for a period of time, the panel will display AC mode that represents turn on the machine successfully, then will enter the AC mode.

When the normal mains power is connected and press the power-on button then the system will automatically power on. If it is set as AC output priority, after a period of time, the panel will display the AC mode to indicate that the power-on is complete and enter the AC mode.

➤ Battery boot

Connect to battery, press the power-on button to establish a working power source.


The system will automatically turn on, after waiting for a period of time, the panel will display battery mode that represents turn on the machine successfully, then will enter the battery mode.

5.1.2 Shutdown steps

When the system is in battery mode or AC mode output, press the switch again, then the system will be turned off.

5.2 Operation and Display Panel

The operation and display panel, shown in below chart , is on the front panel of the inverter. It includes three indicators , four function keys and a LCD display, indicating the operating status and input/output power information.




LED Indicator

LED Indicator			Messages
AC / INV	Green	Solid On	Output is powered by utility in Line mode.
		Flashing	Output is powered by battery or PV in battery mode.
CHG	Green	Solid On	Battery is fully charged.
		Flashing	Battery is charging.
FAULT	Red	Solid On	Fault occurs in the inverter.
		Flashing	Warning condition occurs in the inverter.

Function Keys


Function Key	Description
ESC	To exit setting mode
UP	To go to previous selection
DOWN	To go to next selection
ENTER	To confirm the selection in setting mode or enter setting mode

LCD Display Icons




Three inverters in parallel:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)




2-1. Parallel operation in single phase

Two inverters in parallel:


Power Connection(Each photovoltaic panel needs to be connected to an independent system)



Communication Connection



Lithium battery BMS communication connection (lithium battery BMS and inverter BMS connection)



Icon	Function
Input source information	
AC	Indicates the AC input
PV1	Indicates the 1 st PV panel input
PV2	Indicates the 2 nd PV panel input
Left digital display information	
INPUT BATT M 888 VA Hz	Indicate input voltage, input frequency, battery voltage, V1 voltage, PV2 voltage, charger current
Middle digital display information	
88 88	Indicates the setting programs.
88 88	Indicates the warning and fault codes. Warning: Flashing 88 with warning code Fault: display 88 with fault code
Right digital display information	
OUTPUTBATTLOAD 888 M kWh VA % Hz	Indicate the output voltage, output frequency, load percent, load VA, load W, PV1 charger power, PV2 charger power, DC discharging current.
Battery information	
	Indicates battery level by 0-24%,25-49%,50-74% and 75-100% and charging status.
AGM FLD USER	Indicates the battery type: AGM, Flooded or User-defined battery.
Load information	
OVER LOAD	Indicates overload.
100% 25%	Indicates the load level by 0-24%,25-50%,50-74%,and 75-100%.
	0%~25% 25%~50% 50%~75% 75%~100%
Mode operation information	
	Indicates unit connects to the mains.
PV1	Indicates unit connects to the 1 st PV panel
	Indicates the solar charger is working
	Indicates the DC/AC inverter circuit is working.
Mute operation	
	Indicates unit alarm is disabled.

Display Setting

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: input voltage, input frequency, PV voltage, charging current, battery voltage, output voltage, output frequency, load percentage, load in Watt, load in VA, load in Watt, DO discharging current, main board firmware version and SCC firmware version.

Select item	LCD display
Input voltage and output voltage (Default Display Screen)	Input Voltage=230V, output voltage=230V
Input frequency and output frequency	Input frequency=50.0Hz, output frequency=50.0Hz
Battery voltage and output voltage	Battery Voltage=48.0V, output voltage=230V
Battery voltage and load percentage	Battery Voltage=48.0V, load percentage 68%

Recommended breaker specification of battery for each inverter:

Rated Capacity	1 unit*
5.5KW	150A/70VDC
11KW	300A/70VDC

*If you want to use only one breaker at the battery side for the whole system, the rating of the breaker should be X times current of 1 unit. "X" indicates the number of inverters connected in parallel.

Recommended breaker specification of AC input with single phase:

Rated Capacity	2 units	3 units	4 units	5 units	6 units	7 units	8 units	9 units
5.5KW	80A/230VAC	120A/230VAC	160A/230VAC	200A/230VAC	240A/230VAC	280A/230VAC	320A/230VAC	360A/230VAC
11KW	120A/230VAC	180A/230VAC	240A/230VAC	300A/230VAC	360A/230VAC	/	/	/

Note1: Also, a circuit breaker should be installed at the AC input of each inverter, and the selection of the circuit breaker should refer to the AC input current of the machine nameplate.

Note2: Regarding three-phase system, you can use 4-pole breaker directly and the rating of the breaker should be compatible with the phase current limitation from the phase with maximum units.

Recommended battery capacity


Inverter parallel numbers	2	3	4	5	6	7	8	9
Battery Capacity for 5.5KW	400AH	600AH	800AH	1000AH	1200AH	1400AH	1600AH	1800AH
Battery Capacity for 11KW	500AH	750AH	1000AH	1250AH	1500AH	/	/	/

WARNING! Be sure that all inverters will share the same battery bank. Otherwise, the inverters will transfer to fault mode.

Appendix I: Parallel function

1. Mounting the unit

When installing multiple units, please follow below chart.



NOTE: For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit, Be sure to install each unit in the same level.

2. Wiring Connection

NOTICE: It's requested to connect to battery for parallel operation.

The cable size of each inverter is shown as below:

Recommended battery cable and terminal size for each inverter:

Rated Capacity	Wire Size	Ring Terminal			Torque value	Ring terminal:
		Cable mm ²	Dimensions D (mm)	L (mm)		
5.5KW	1*2AWG	38	6.4	39.2	2~3Nm	
11KW	1*2/0AWG	85	8.4	54	5Nm	

WARNING: Be sure the length of all battery cables is the same. Otherwise, there will be voltage difference between inverter and battery to cause parallel inverters not working.

Recommended AC input and output cable size for each inverter:

Rated Capacity	AWG no.	Torque
5.5KW	10AWG	1.2~1.6Nm
11KW	8AWG	1.4~1.6Nm





You need to connect the cables of each inverter together. Take the battery cables for example: You need to use a connector or bus-bar as a joint to connect the battery cables together, and then connect to the battery terminal. The cable size used from joint to battery should be X times cable size in the tables above. indicates the number of inverters connected in parallel.

Regarding AC input and output, please also follow the same principle.

WARNING!! Make sure all output N wires of each inverter must be connected all the time. Otherwise, it will cause inverter fault in error code #72.

CAUTION!! Please install the breaker at the battery and AC input side. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of battery or AC input.

Battery voltage and load in VA	Battery Voltage=48.0V, load in VA=1.08kVA
Battery voltage and load in Watt	Battery Voltage=48.0V, load in Watt=1.88kW
PV1 voltage and PV1 charger power	PV1 Voltage=360V, charging power=1.58kW
Charger current and DC discharging current	Charging current=30A, discharging current=0A
PV energy generated today	Today energy = 6.3kWh

PV energy generated this month	This month energy = 358kWh. 
PV energy generated this year	This year energy = 8.32MWh 
PV energy generated totally	Total energy = 13.9MWh 
Real date	Real date Nov 28, 2016. 
Real time	Real time 13: 20. 

7. Technical datasheet

Model		5548MH	11048MH
Capacity		5500VA/6500W	11000VA/12000W
Input	Rated Input Voltage	230VAC	
	Voltage Range	170-280VAC(UPS Mode)90-280VAC(INV Mode)	
	Frequency	50Hz/60Hz(Auto Adaptive)	
Output	Output Voltage	230VAC±5%	
	Peak Power	11000VA	22000VA
	Conversion efficiency (max)	98%	
	Output Frequency	50Hz/60Hz±0.1%	
	Transfer Time (adjustable)	10ms (computer equipment), 30ms (home appliances)	
	Waveform	Pure Sine Wave	
Solar charging and mains charging	No-load consumption	<55W	<80W
	PV Charging Mode	MPPT	
	MAX.PV Input Power	8500W	2x5500W
	MPPT Tracking Range	60-500Vdc	90-500Vdc
	MAX.PV Charging Current	100A	150A
	MAX.AC Charging Current	100A	150A
Display	MAX.Charging Current	100A	150A
	LCD Display	Display Running Mode/Loads/Input/Output etc.	
Interface	RS232	5PIN/Pinch2.0mm, Baud Rate 2400	
	Communication Port	Lithium Battery BMS Communication Card WifiCard, Dry Contact	
Environments	Parallel Connect Interface	With Parallel	
	Operating Temperature	-10~50°C	
	Humidity	20%-95%(Non-condensing)	
	Storage Temperature	-15~50°C	
	Altitude	Altitude Not Over 1000m,Derating over 1000m,Max 4000m, Refer to IEC62040	
Environments	Noise	50db	



6. Trouble removal

Problem	LCD/LED/Buzzer	Explanation/Possible cause	What to do
Unit shuts down automatically during startup process.	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low (<1.91V/Cell)	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication	1. The battery voltage is far too low.(<1.4V/Cell) 2. Internal fuse tripped.	1.Contact repair center for replacing the fuse. 2. Re-charge battery. 3. Replace battery.
Mains exist but the unit works in battery mode.	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
	Green LED is flashing	Insufficient quality of AC power. (Shore or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied)is working well or if input voltage range setting is correct.(UP-->sppliance)
	Green LED is flashing.	Set "Solar First" as the priority of output source.	Change output source priority to Utility first.
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.
Buzzer beeps continuously and red LED is on.	Fault code 07	Overload error. The inverter is overload 105% and time is up.	Reduce the connected load by switching off some equipment.
		If PV input voltage is higher than specification, the output power will be derated.At this time, if connected loads is higher than derated output power, it will cause overload.	Reduce the number of PV modules in series or the connected load.
	Fault code 05	Output short circuited.	Check if wiring is connected well and remove abnormal load.
		Temperature internal converter component is over 120°C.	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
	Fault code 02	Internal temperature of inverter component is over 100°C	
	Fault code 03	Battery is over-charged	Return to repair center.
		The battery voltage is too high.	Check if spec and quantity of batteries are meet requirements.
	Fault code 01	Fan fault	Replace the fan.
	Fault code 06/58	Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac)	1. Reduce the connected load. 2. Return to repair center
	Fault code 08/09/53/57	Internal components failed.	Return to repair center.
	Fault code 51	Over current or surge.	Restart the unit, if the error happens again, please return to repair center.
	Fault code 52	Bus voltage is too low.	
	Fault code 55	Output voltage is unbalanced.	
	Fault code 59	PV input voltage is beyond the specification.	Reduce the number of PV modules in series.

Main board firmware version	Version 00001.00
-----------------------------	------------------

Operating Mode Description


Operating mode	Behaviors	LCD display
Standby mode Note: *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. *Power swing mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.	No output power, solar or utility charger available	Battery is charged by utility.
		Battery is charged by PV energy.
		Battery is charged by utility and PV energy.
		Battery is charged by PV energy and feed PV energy grid.
		No charging.
Line mode	Output power from utility. Charger available	Utility charges battery and provides power to load.
		Utility and battery power provide power to load.

Line mode	Output power from utility. Charger available	PV energy, battery power and utility provide power to load. 
	Output power from utility. Charger available	PV energy and utility charge battery, and utility provides power to load. 
		PV energy charges battery, utility and PV energy provide power to the load. 
		PV energy charges battery, PV energy provides power to the load and feeds remaining energy to the grid. 
Battery mode	Output power from battery or PV	PV energy charges battery, PV energy provides power to the load and feeds remaining energy to the grid. 
		PV energy and battery energy supply power to the load. 
		Battery provides power to the load. 
Only PV mode	Output power from PV	PV provides power to the load. 

5.5.2 Warning Descriptions

➤ **Alarm:** The red LED flashes, and the LCD displays an alarm code, the inverter does not enter the failure mode

Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon flashing
01	Fan is locked when inverter is on.	Beep three times every second	
02	Over temperature	None	
03	Battery is over-charged	Beep once every second	
04	Low battery	Beep once every second	
07	Overload	Beep once every 0.5 second	
10	Output power derating	Beep twice every 3 seconds	
15	PV energy is low.	Beep twice every 3 seconds	
16	High AC input (>280VAC) during BUS soft start	None	
E9	Battery equalization	None	
bP	Battery is not connected	None	

5.5.3 Code Reference

Related information code will be displayed on LCD screen. Please check inverter LCD screen for the operation.

Code	Description
60 	If battery status is not allowed to charge and discharge after the communication between the inverter and battery is successful, it will show code 60 to stop charging and discharging battery.
61 	Communication lost - After battery is connected, communication signal is not detected for 1 minutes, buzzer will beep. - Communication lost occurs after the inverter and battery is connected successfully, buzzer beeps immediately.
69 	If battery status is not allowed to charge after the communication between the inverter and battery is successful, it will show code 69 to stop charging battery.
70 	If battery status must to charge after the communication between the inverter and battery is successful, it will show code 70 to charge battery.
71 	If battery status is not allowed to discharge after the communication between the inverter and battery is successful, it will show code 71 to stop discharge battery.

5.5 Fansion and alarm description

5.5.1 Faults Descriptions

➤ **Fault:** The inverter enters the fault mode, the red LED light is always on and the LCD displays the fault code.

Fault Reference Code








Fault Code	Fault Event	Icon on
01	Fan is locked when inverter is off.	
02	Over temperature or NTC is not connected well.	
03	Battery voltage is too high.	
04	Battery voltage is too low.	
05	Output short circuited or over temperature is detected by internal converter components.	
06	Output voltage is too high.	
07	Over load time out.	
08	Bus voltage is too high	
09	Bus soft start failed	
51	Over currents or surge	
52	Bus voltage is too low	
53	Inverter soft start failed	
55	Over DC voltage in AC output	
57	Current sensor failed	
58	Output voltage is too low	
59	PV voltage is over limitation	

5.3 LCD Setting

After pressing and holding ENTER button for 3 seconds, the unit will enter setting mode. Press “UP” or “DOWN” button to select setting programs. And then, press “ENTER” button to confirm the selection or ESC button exit.


Setting Programs:

Program	Description	Selectable option	
00	Exit setting mode	Escape 	
01	Output source priority selection	SUB	Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, Utility energy will supply power to the loads at the same time.
		SBV	Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12 or solar and battery is not sufficient.
02	Maximum charging current: To configure total charging current for solar and utility chargers. (Max. charging current = utility charging current + solar charging current)	60A(default) 60 ^A	Setting range is from 10A to maximum charging current. Increment of each click is 10A.
03	AC input voltage range	Appliances (default) APL	If selected, acceptable AC input voltage range will be within 90-280VAC.
		UPS UPS	If selected, acceptable AC input voltage range will be within 170-280VAC.

05	Battery type	AGM (default) 	Flooded 
		User-Defined 	If "User-Defined" is selected, battery charge voltage, low DC cut-off voltage and dual cut-off voltage can be set up in program 24,26,27,29 and 61.
		LIA-protocol compatible battery 	If selected, programs of 24,26,27 and 29 will be automatically set up. No need for further setting.
		Pylontech battery 	
		Techfine battery 	
		Growatt battery 	
		LIB-protocol compatible battery 	Select "LIB if using Lithium battery compatible to Lib protocol. If selected, programs of 26,27 and 29 will be automatically set up. No need for further setting.
06	Auto restart when overload occurs	Restart disable(default) 	Restart enable 
		Restart disable (default) 	Restart enable 


※ When to Equalize

In stage, when the setting equalization interval(battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




※ Equalize charging time and timeout


In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage raises to battery equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.



However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage.



When the BMS/485 communication interface is externally connected, as shown in the following figure:



Communication Connection

Please use supplied communication cable to connect to inverter and PC. Please install a monitoring software on the computer.

Dry Contact Signal

There is one dry contact (3A/250VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.

Unit Status		Condition		Dry contact port: 	
				NC & C	NC & C
Power Off	Unit is off and no output is powered.			Close	Open
Power On	Output is powered from battery or solar.	Normal mode	Battery voltage< Low DC warning voltage	Open	Close
			Battery voltage> Float charging voltage	Close	Open
		Solar first mode	Battery voltage< Solar to AC voltage	Open	Close
			Battery voltage> AC to DC voltage	Close	Open








5.4 Battery Equalization Description

Equalization function is added into charge controller, It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.

※ How to Apply Equalization Function


You must enable battery equalization function in monitoring LCD setting program 30 first. Then, you may apply this function in device by either one of following methods:






- 1.Setting equalization interval in program 35.
- 2.Active equalization immediately in program 36.

08	ECO function: System will temporarily stop when the load is low in battery mode.	disable (default) 	
		enable 	
09	Output frequency	50Hz(default) 	60Hz 
		220V 	230V (default) 
10	Output voltage	240V 	
11	Maximum utility charging current Note: If setting value in program 02 is smaller than that in program in 11, the inverter will apply charging current from program 02 for utility charger.	30A(default) 	Setting range is 2A, then from 10A to max.AC charging current. Increment of each click is 10A.
12	Setting voltage point back to utility source when selecting"SBU priority" in program 01.	Available options in 24 system model:	
		23.0V (default) 	Setting range is from 22V to 25.5V. Increment of each click is 0.5V.
		Available options in 48 system model:	
		46V (default) 	Setting range is from 44V to 51V. Increment of each click is 1V.
13	Setting voltage point back to battery mode when selecting"SBU priority" in program 01.	Available options in 24 system model:	
		Battery fully charged 	27V(default) 
		Setting range is from 24V to 29V. Increment of each click is 0.5V.	
		Available options in 48 system model:	
		Battery fully charged 	54V (default) 
		Setting range is from 48V to 58V. Increment of each click is 1V.	

16	Charger source priorit: To configure charger source priority	If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below:	
		Solar first 	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.
		Solar and Utility(default) 	Solar energy and utility will charge battery at the same time.
		Only Solar 	Solar energy will be the only charger source no matter utility is available or not.
		If this inverter/charger is working in Battery mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.	
18	Alarm control	Alarm on (default) 	Alarm off
19	Auto return to default display screen	Return to default display screen (default) 	If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) after no button is pressed for 1 minute.
		Stay at latest screen 	If selected, the display screen will stay at latest screen user finally switches.
20	Backlight control	Backlight on (default) 	Backlight off
22	Beeps while primary source is interrupted	Alarm on (default) 	Alarm off
23	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	Bypass disable (default) 	Bypass enable
24	Battery low voltage ● If battery power is only power source available inverter will alarm.	Battery low voltage 44.0V 	
		Setting range is from 20.0V-27.0V for 24V system and 40.0V-54.0V for 48V system.	

60	Dual output	Disable(default) 	Use
61	Enter the dual output functional voltage point	Default setting:44.0V 	
		Default setting:22.0V 	
		If battery voltage lower than inverter setting, second output will be cutted of, Increment of each click is 0.1V.	
62	Enter the dual output functional SOC point		If any type of lithium battery is selected in program 5. If BMS capacity lower than SOC setting, second output will be cutted of.
63	Dual battery voltage receiver		Default 52V/26V,if the battery voltage is higher than the inverter setting, the dual will be restored.
64	Dual battery SOC Receiver		If any type of lithium battery is selected in program 5. Default 50%,if the BMS capacity is higher than the SOC setting, the second output will be restored.
65	Setting discharge time on the second output	Disable(default) 	Setting range is disable and then from 0 min to 990 min. Increment of each click is 5 min. *If the battery discharge time achieves the setting time in program 61 and the program 60 function is not triggered, the output will be turned off.
66	Dual Recover Delay Time		The value ranges from 0-60min.
67	Output Open Time		The value ranges from 0 to 23.
68	Output Stop Time		The value ranges from 0 to 23.

48	Scheduled time for AC output on	00:00(Default)  The setting range of scheduled Time for AC output off is from 00:00 to 23:00, increment of each click is 1 hour.	
49	Scheduled time for AC output off	00:00(Default)  The setting range of scheduled Time for AC output off is from 00:00 to 23:00, increment of each click is 1 hour.	
50	Set country customized regulations	Mode 1 	If selected, acceptable feed-in grid voltage range will be 195.5-253VAC. Acceptable feed-in grid frequency range will be 49-51Hz.
		Mode 2 	If selected, acceptable feed-in grid voltage range will be 184-264.5VAC. Acceptable feed-in grid frequency range will be 47.5-51.5Hz.
		Mode 3 	If selected, acceptable feed-in grid voltage range will be 184-264.5VAC. Acceptable feed-in grid frequency range will be 57-62Hz.
		Mode 4(Default) 	If selected, acceptable feed-in grid voltage range will be 170-264.5VAC. Acceptable feed-in grid frequency range will be 47.5-51.5Hz.
51	Time setting-Minute	 For minute setting, the range is from 00 to 59.	
52	Time setting-Hour	 For hour setting, the range is from 00 to 23.	
53	Time setting-Day	 For day setting, the range is from 00 to 31.	
54	Time setting-Month	 For month setting, the range is from 1 to 12	
55	Time setting-Year	 For year setting, the range is from 16 to 99.	
56	GRID-tie current	^{10A} 	Increment of each click is 1A.

25	Record fault code	Record enable (default) 	Record disable 
26	Bulk charging voltage (C.V voltage)	24V system default setting:28.2V 	
		48V system default setting:56.4V 	
		If self-defined is selected in program 5, this program can be set up. Setting range is from 24.0V to 30.0V for 24V system and 48.0V to 60.0V for 48V system. Increment of each click is 0.1V.	
27	Floating charging voltage	24V system default setting:27.0V 	
		48V system default setting:54.0V 	
28	Reset factory setting	default: 	
		48V system default setting:54.0V 	
29	Low DC cut-off voltage: • If battery power is only power source available inverter will shut down. • If PV energy and battery power are available, inverter will charge battery without AC output.	24V system default setting:21.0V 	
		48V system default setting:42.0V 	
		If self-defined is selected in program 5, this program can be set up. Setting range is from 20.0V to 26.0V for 24V system and 40.0V to 52.0V for 48V system. Increment of each click is 0.1V Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.	

30	Battery equalization	Battery equalization 30 EEN	Battery equalization disable (default) 30 EdS
		If "Flooded" or "User Defined" is selected in program 05, this program can be set up.	
31	Battery equalization voltage	24V system default setting: 29.2V EV 31 ^{BATT} 29.2V	
		48V system default setting: 58.4V EV 31 ^{BATT} 58.4V	
		Setting range is from 24.0V to 30.0V for 24V system and 48.0V to 60.0V for 48V system. Increment of each click is 0.1V.	
33	Battery equalized time	60min (default) 33 60	Setting range is from 5min to 900min. Increment of each click is 5min.
34	Battery equalized timeout	120min (default) 34 120	Setting range is from 5min to 900min. Increment of each click is 5min.
35	Equalization interval	30days (default) 35 30d	Setting range is from 0 to 90 days. Increment of each click is 1 day.
36	Equalization activated immediately	Enable 36 AEN	Disable (default) 36 AdS
		If equalization function is enabled in program 30, this program can be set up. If "Enable" is selected in this program, it's to activate battery equalization immediately and LCD main page will show "EQ". If "Disable" is selected, it will cancel equalization function until next activated equalization time arrives based on program 35 setting. At this time, "EQ" will not be shown in LCD main page.	
37	BMS Function Switch	off (default) bns 37 OFF	Whether to enable the BMS communication function
		bns 37 ON	

38	Bat Soc Under Lock	bSU 38 ^{BATT} 10%	If any type of lithium battery is selected in program 5. BMS low voltage SOC value, if the BMS SOC value is lower than the set value, the inverter will shut down to protect the battery.
39	Bat Soc Turn To Ac	StC 39 ^{BATT} 20%	If any type of lithium battery is selected in program 5. When the working mode of the inverter is set to the battery priority mode, the inverter will be forced to enter the mains charging when the SOC of the BMS is lower than the set value.
40	Bat Soc Turn To Dc	Stb 40 ^{BATT} 95%	If any type of lithium battery is selected in program 5. When the working mode of the inverter is set to the battery priority mode, the inverter resumes the DC working mode when the SOC of the BMS is higher than the set value.
41	Bat Restart Soc	bSt 41 ^{BATT} 50%	If any type of lithium battery is selected in program 5. When the inverter is turned on, the SOC must be higher than the set value to work normally.
43	Solar supply priority	43 bLU	Solar energy provides power to charge battery as first priority.
		43 LbU	Solar energy provides power to the loads as first priority.
44	Solar energy feed to grid configuration	44 Gfd	Solar energy feed to grid disable.
		44 GfE	Solar energy feed to grid enable.
45	Reset PV energy storage	Notre set (Default) 45 nrt	Reset 45 rSt
46	Start charging time for AC charger	00:00 (Default) StA 46 ^{BATT} 000 ^h The setting range of start charging time for AC charger is from 00:00 to 23:00, increment of each click is 1 hour.	
47	Stop charging time for AC charger	00:00 (Default) StO 47 ^{BATT} 000 ^h The setting range of scheduled Time for AC output on is from 00:00 to 23:00, increment of each click is 1 hour.	